



DT152 OWNER'S MANUAL

Thank you for purchasing
the DynaTrap® Insect Trap!

This product may be covered by one or more U.S. patents
or pending patent applications. See www.DynaTrap.com/patents



IMPORTANT: READ CAREFULLY IMPORTANT SAFETY INSTRUCTIONS SAVE THESE INSTRUCTIONS

INSTRUCTIONS PERTAINING TO A RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

WARNING: when using electric appliances, basic precautions should always be followed, including the following:

1. Please read all instructions before using the DynaTrap® Insect Trap and keep for future reference.
2. To disconnect, remove plug from outlet.
3. To reduce the risk of injury from moving parts or electric shock, always disconnect plug before servicing or cleaning.
4. Do not position the unit near heat, gas, oil or other flammable materials.
5. Place out of reach from children.
6. To reduce the risk of electrical shock, do not put appliance in water or other liquid.
7. Never operate this product if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or if it has been dropped into water or other liquid.
8. Do not insert fingers or any foreign objects into the unit while it is connected to an electrical outlet.
9. Collected insects within the unit may contribute to fire, so clean insects from the unit frequently.
10. Do not clean this product with water spray. Do not place where it can fall into water, or near flammable materials.
11. Do not touch fan while in motion.
12. Do not abuse cord — never carry or hang unit by cord or yank it to disconnect from receptacle. Keep cord away from sharp edges.
13. Use only extension cords that have plug and receptacles that match the product plug. Replace or repair damaged cords.
14. Only use attachments recommended or sold by the manufacturer.

INSTALLATION & OPERATING INSTRUCTIONS

1. Unpack unit. Save carton for storage (if needed).
2. The unit will turn on automatically when plugged in. For best catch results, leave the trap on and running, 24/7.
3. Catch rate activity will be higher at night. For best catch results it is recommended to keep the unit away from competing light sources.
4. This unit is for indoor, household and commercial use only.
5. Remove liner from StickyTech™ Glue Card and place in base of retaining cage (Glue side up).

FCC COMPLIANCE

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired

operation. **CAUTION:** Changes or modifications not approved by the party responsible for compliance could void user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


CLEANING

Frequent cleaning will prolong the life of the unit, ensure fire prevention and provide for more efficient operation.

1. Be sure to clean the unit at least once per month.
2. Unplug the unit. **CAUTION:** There may be insects still alive when opening the trap.
3. For monthly cleaning, remove the catch basket by turning it to the left. Remove any buildup from the inside of the catch basket and fan with a brush.
4. When replacing the catch basket — DO NOT press/push against the screen windows.
5. Clean prior to storage.
6. Replace StickyTech™ Glue Cards every 30 Days, or as needed.
7. Remove liner from new StickyTech™ Glue Card to expose glue and place Glue Card (Glue side up) in bottom of catch basket.

HOW THE DYNATRAP® INSECT TRAP WORKS

Flying insects are attracted to the DynaTrap® by dual-wavelength UV-LED bulbs and CO2 that is generated by the photocatalysis between the UV light and special TiO2 coating. The whisper-quiet fan then pulls the insects into the ultra-fine mesh catch basket, trapping them on the StickyTech™ Glue Card, where they are unable to escape. The catch basket can be removed, allowing the contents to be periodically emptied into the trash. Monitor the insects trapped in the catch basket and replace with a fresh StickyTech™ Glue Card every 30 days, or as needed.



TROUBLESHOOTING

Problem:	Possible cause:	Correction:
Light does not illuminate and fan does not spin.	No electrical power.	1. Check plug, receptacle, fuse or circuit breaker.
Light illuminates, but fan does not spin.	Shorted fan.	UNPLUG UNIT: Examine fan to see that it is free from foreign material, dirt or buildup of dead insects. Clean unit as in "CLEANING" section.
Fan spins, but light does not illuminate.	Burnt out light.	The UV-LED's have an expected lifespan of 20,000 hours and are not replaceable. If light fails to illuminate before 20,000 hours of operation, contact customer service: dynatrap@woodstream.freshdesk.com

LIMITED WARRANTY

DYNAMIC guarantees to the original purchaser that this product is free from defective materials and workmanship. This warranty is limited to remedy any defective part for a period of one year from date of original date of purchase. Retain your original receipt as proof of purchase. This warranty does not apply to the light bulb, nor to, in our judgment, misuse or abuse. If this unit has been altered, no warranty is in force. This warranty does not apply if this unit is purchased outside the United States, Canada and Mexico. In no case shall DYNAMIC be liable for any accidental, punitive, consequential, or any other damages of any kind for breach of this or any other warranty, expressed or implied, whatsoever. Some states do not allow limitation on how long an implied warranty lasts, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state.

REPLACEMENT PARTS

21523 StickyTech™ Glue Card Refill

To see all replacement and accessory parts available for your DynaTrap, visit www.DynaTrap.com.

SAVE THESE INSTRUCTIONS

Dynamic Solutions Worldwide, LLC
69 N. Locust St., Lititz, PA 17543
1-877-403-8727 (TRAP)
dynatrap@woodstream.freshdesk.com
www.DynaTrap.com

**FOR HOUSEHOLD AND COMMERCIAL,
INDOOR USE ONLY**

SEE THE ELECTRICAL SPECIFICATIONS ON YOUR PRODUCT LABEL.

This device complies with Performance Standards for
Light-Emitting Products, 21 CFR, Part 1040, Chapter 1,
Subchapter J, Radiological health.